




| Original  | Replacement   | Original   | Replacement   |
|---|---|--|---|
|  On/Stand-by             |  Power   |  On/Stand-by Tv |  Shift + Power |
|  Dolby Virtual Speaker   |  Media   |  Input Tv       |  AV            |
|  News                    |  Blue    |  CH+ Tv         |  Up            |
|  Cinema/Game             |  Green   |  CH- Tv         |  Down          |
|  Sport                   |  Yellow  |  Vol+ Tv        |  Shift + Vol + |
|  Standard                |  Red     |  Vol- Tv        |  Shift + Vol - |
|  Digital 1-2             |  1       |  |   |
|  Line 1-2                |  2       |  |   |
|  Vol+                    |  Vol +   |  |   |
|  Vol-                    |  Vol -   |  |   |
|  Bass/Treble             |  Options |  |   |
|  Dimmer/Sens             |  Dual    |  |   |
|  Mute                  |  Mute  |  |   |
|  Subwoofer Level       |  Ch +  |  |   |
|  Subwoofer Level Down  |  Ch -  |  |   |
|  Center Spk Level      |  >>    |  |   |
|  Center Spk Level Down |  <<    |  |   |

