



| Original   | Replacement  |
|--|--|
|  Power    |  Power              |
|  Mute     |  Mute / Dimmer      |
|  Picture  |  Picture / Format   |
|  Sound    |  Sound / Title      |
|  Zoom     |  Zoom / Size        |
|  Subtitle |  Subtitle / EQ      |
|  EPG      |  Guide / EPG / -/-- |
|  FAV      |  Fav / Marker / PC  |
|  1        |  1                  |
|  2       |  2                 |
|  3      |  3                |
|  4      |  4                |
|  5      |  5                |
|  6      |  6                |
|  7      |  7                |
|  8      |  8                |
|  9      |  9                |

| Original  | Replacement   |
|---|---|
|  CHN List      |  Smart / List            |
|  0             |  0                       |
|  Return / Back |  Back / Return           |
|  Menu          |  Menu / Home             |
|  Up            |  Up                      |
|  Source        |  AV / Input / RDS        |
|  Left          |  Left                    |
|  Enter         |  OK                      |
|  Right         |  Right                   |
|  Down         |  Down                   |
|  Exit        |  Exit / Cancel / Clear |
|  TV / Radio  |  TV/Radio /            |
|  Vol +       |  Vol+                  |
|  Home        |  D.Menu / Top          |
|  PR +        |  CH+ / Page+           |
|  Vol -       |  Vol-                  |
|  PR -        |  CH- / Page-           |



