



| Original | Replacement | Original | Replacement |
|---|--|---|---|
|  Power |  Power |  Vol + |  Vol + |
|  TV / RAD |  TV/R |  Vol - |  Vol - |
|  Energy Saving |  3D |  Mark / Fav |  Pre Ch |
|  AV Mode |  Shift + AV |  Mute |  Mute |
|  Input |  AV |  P + / Page + |  Ch + |
|  1 |  1 |  P - / Page - |  Ch - |
|  2 |  2 |  Menu |  Menu |
|  3 |  3 |  Ratio |  Format |
|  4 |  4 |  Q.Menu |  D. Menu |
|  5 |  5 |  Up |  Up |
|  6 |  6 |  Right |  Right |
|  7 |  7 |  Down |  Down |
|  8 |  8 |  Left |  Left |
|  9 |  9 |  OK |  Ok |
|  0 |  0 |  Guide |  Guide |
|  List |  List |  Info |  Info |
|  Q.View |  Media |  Return / Exit |  Exit |





| Original | Replacement | Original | Replacement |
|---|---|----------|-------------|
|  Return / Exit |  Back | | |
|  Red |  Red | | |
|  Green |  Green | | |
|  Yellow |  Yellow | | |
|  Blue |  Blue | | |
|  Text |  Text | | |
|  T.Opt |  Options | | |
|  Subtitle |  Subt | | |
|  Stop |  Stop | | |
|  Play |  Play | | |
|  Pause |  Pause | | |
|  << |  << | | |
|  >> |  >> | | |
|  << |  I<< | | |
|  >> |  >>I | | |
|  Simplink |  Smart | | |

