

































Original	Replacement
 Power	 Power
 TV / Radio	 TV/Radio /
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Goto	 Shift + Text /
 0	 0
 Fav	 Fav / Marker / PC
 Info	 Info / Angle
 CH Back	 Back / Return

Original	Replacement
 Menu	 Menu / Home
 Up / CH +	 Shift + Up
 Up / CH +	 Up
 Exit	 Exit / Cancel / Clear
 Left / Vol -	 Shift + Left
 Left / Vol -	 Left
 OK	 OK
 Right / Vol +	 Shift + Right
 Right / Vol +	 Right
 EPG	 Guide / EPG / -/-
 Down / CH -	 Shift + Down
 Down / CH -	 Down
 TXT	 Text / Goto
 SUB	 Subtitle / EQ
 Audio	 Audio / Lang I/II
 << REV	 << / Tune-
 >> FWD	 >> / Tune+





	Original	Replacement	Original	Replacement
	I<< Prev	 I<< / Preset-		
	>>I Next	 >>I / Preset+		
	Play	 Play / Slow		
	Pause	 Pause / Step / Freeze		
	Stop	 Stop / Hold		
	Repeat	 Shift + Green / APP / REPEAT		
	Page +	 CH+ / Page+		
	Page -	 CH- / Page-		
	PVR	 Smart / List		
	Rec	 Rec / Rec Mode		
	Red	 Red / Netflix / Search		
	Green / V-Format	 Shift + Yellow / YouTube / REPEAT A-B		
	Green / V-Format	 Green / APP / Repeat		
	Yellow / Aspect	 Yellow / YouTube / Repeat		
	Blue / Timer	 Shift + Blue / Prime / Prime		
	Blue / Timer	 Blue / Prime Video / Random		

