











































































Original		Replacement		Original		Replacement	
	Power		Power		Rec		Rec
	Mute		Mute		<<		<<
	1		1		>>		>>
	2		2		<< / >		<<
	3		3		>> / <		>>
	4		4		Red		Red
	5		5		Green		Green
	6		6		Yellow		Yellow
	7		7		Blue		Blue
	8		8		Media		Media
	9		9		Guide		Guide
	0		0		Up		Up
	TV Portal		Smart		Left		Left
	Menu		Menu		OK		Ok
	Play		Play		Right		Right
	Pause		Pause		Down		Down
	Stop		Stop		Exit		Exit





Original	Replacement
 Back	 Back
 Vol +	 Vol +
 Vol -	 Vol -
 List	 List
 i	 Info
 P+ / Page +	 Ch +
 P- / Page -	 Ch -
 OPT+	 Options
 Sound	 Dual
 SUB	 Subt
 TV / Radio	 TV/R
 Text	 Text
 + Book	 Shift + Pre Ch
 Book	 Pre Ch
 I>	 Shift + Right
 Source	 AV
 Sleep	 Sleep

Original	Replacement
 V-Format	 Format
 Wide	 3D

