


















































	Original	Replacement		Original	Replacement
	Power		Power		Recall
	Mute		Mute		Back
	[i+]/[?]		Info		List
	A/B/[+]		TV/R		Sleep
	Input/[+]		AV		Vol +
	[]		Smart		Vol -
	1		1		Ch +
	2		2		Ch -
	3		3		Dual
	4		4		Menu
	5		5		Up
	6		6		Left
	7		7		Ok
	8		8		Right
	9		9		Down
	0		0		Text
	-/--		Guide		Red
					Green





Original	Replacement	Original	Replacement
 Yellow	 Yellow		
 Blue/[+]	 Blue		

