



















































	Original	Replacement		Original	Replacement
	Power		Power		Recall
	Mute		Mute		Back
	[i+]/[?]		Info		List
	A/B/[+]		TV/R		Sleep
	Input/[+]		AV		Vol +
	[ ]		Smart		Vol -
	1		1		Prog+
	2		2		Prog-
	3		3		(↔)
	4		4		Menu
	5		5		Up
	6		6		Left
	7		7		OK
	8		8		Right
	9		9		Down
	0		0		[≡]
	-/--		Guide		Red/Sound
					Green/*



