























































	Original	Replacement		Original	Replacement
	Power				CH +
	ShowView				Ch -
	AV				Vol +
	Direct Tv Rec				Vol -
	Rec				HDD
	1				DVD
	2				<< Slow/Search
	3				Slow/Search >>
	4				Stop
	5				Pause
	6				Play
	7				Top Menu / Direct Navigator
	8				Menu / Play List
	9				Up
	0				Left
	-/--		Guide		Enter
	Cancel		Exit		Right

	Original	Replacement		Original	Replacement
	Power				CH +
	ShowView				Ch -
	AV				Vol +
	Direct Tv Rec				Vol -
	Rec				HDD
	1				DVD
	2				<< Slow/Search
	3				Slow/Search >>
	4				Stop
	5				Pause
	6				Play
	7				Top Menu / Direct Navigator
	8				Menu / Play List
	9				Up
	0				Left
	-/--		Guide		Enter
	Cancel		Exit		Right



