





























































Original	Replacement
 Power	 Power
 Tv/Radio	 TV/R
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 EPG	 Guide
 Recall	 Back
 Menu	 Menu
 FAV	 Pre Ch

Original	Replacement
 Info	 Info
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 CH+	 Ch +
 CH-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Red/F1	 Red
 Green/F2	 Green
 Yellow/F3	 Yellow
 Blue/F4	 Blue
 Subt	 Subt
 Audio	 Dual





	Original	Replacement	Original	Replacement
	TXT	 Text		
	Zoom	 Eject		
	Play/Pause	 Play		
	Stop	 Stop		
	I>/Slow	 Pause		
	Rec	 Rec		
	<<	 <<		
	>>	 >>		
	I<<	 I<<		
	>>I	 >>I		

