






































































Original		Replacement		Original		Replacement	
	Power		Power		Yellow / FAV		Pre Ch
	Mute		Mute		Blue / SLP		Blue
	Up / CH+		Up		Zoom		Eject
	Up / CH+		Ch +		Freeze		Pause
	Left / Vol-		Left		Blue / SLP		Sleep
	Left / Vol-		Vol -		DSP / CAPS		Info
	Right / Vol+		Right		Recall		Back
	Right / Vol+		Vol +		1		1
	Down / CH-		Ch -		2		2
	Down / CH-		Down		3		3
	Enter		Ok		4		4
	Menu		Menu		5		5
	Red / P.M		Red		6		6
	Red / P.M		Format		7		7
	Green / S.M		Green		8		8
	Green / S.M		Shift + Dual		9		9
	Yellow / FAV		Yellow		0		0





Original		Replacement		Original		Replacement	
	-/--		Guide				
	Input		AV				
	PIP		Smart				
	POP		Media				
	PIP-POS		Shift + Smart				
	M.Win		TV/R				
	Active-Win		Shift + TV/R				
	Timer		Shift + AV				
	Stereo		Dual				
	Swap		Exit				
	Text		Text				
	Text Mix		Shift + Text				
	Text Hold		Stop				
	Text Update		Options				
	Text Reveal		Subt				
	Text Size		Shift + Eject				

