







































































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 PP	 Back
 P<P	 Pre Ch
 --	 Guide
 Info	 Info
 I-II	 Dual

Original	Replacement
 Up	 Up
 P+	 Ch +
 Down	 Down
 P-	 Ch -
 Right	 Right
 Left	 Left
 M	 Ok
 Vol+	 Vol +
 Vol-	 Vol -
 Red/Sound	 Red
 Green/Picture	 Green
 Yellow/Feature	 Yellow
 Blue/Install	 Blue
 TV	 TV/R
 AV	 AV
 [≡]	 Text
 [/≡]	 3D





	Original	Replacement	Original	Replacement
	[≡o]	Media		
	[≡+]	Subt		
	[≡x]	Exit		
	[≡◇]	Format		
	[≡?]	Options		
	[≡i]	Menu		

