



| Original  | Replacement | Original  | Replacement                |
|---|-------------|---|----------------------------|
|      | Power       |      | Power                      |
|      | Mute        |      | Mute / Dimmer              |
|      | 1           |      | 1                          |
|      | 2           |      | 2                          |
|      | 3           |      | 3                          |
|      | 4           |      | 4                          |
|      | 5           |      | 5                          |
|      | 6           |      | 6                          |
|      | 7           |      | 7                          |
|      | 8           |      | 8                          |
|    | 9           |    | 9                          |
|    | EPG         |    | Guide / EPG / -/--         |
|    | 0           |    | 0                          |
|    | TXT         |    | Text / Goto                |
|    | Vol+        |    | Vol+                       |
|    | Source      |    | AV / Input / RDS           |
|    | P+          |    | CH+ / Page+                |
|    | Vol-        |    | Vol-                       |
|    | Home        |    | Menu / Home                |
|    | P-          |    | CH- / Page-                |
|    | *           |    | Smart / List               |
|    | Up          |    | Up                         |
|    | i           |    | Info / Angle               |
|    | Left        |    | Left                       |
|    | OK          |    | OK                         |
|    | Right       |    | Right                      |
|    | Back        |    | Back / Return              |
|  | Down        |  | Down                       |
|  | Exit        |  | Exit / Cancel / Clear      |
|  | Netflix     |  | Shift + Red / Netflix /    |
|  | YouTube     |  | Shift + Yellow / YouTube / |
|  | prime video |  | Shift + Blue / Prime       |
|  | USB         |  | Shift + 8                  |
|  | Red         |  | Red / Netflix / Search     |



