







































































Original	Replacement
 Power	 Power
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info
 List	 List
 *	 Menu
 Back	 Back
 EPG	 Guide

Original	Replacement
 [→]	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 OK	 Ok
 Netflix	 Media
 YouTube	 Shift + Smart
 Browser	 Shift + Media
 Vol+	 Vol +
 Vol-	 Vol -
 prime video	 Smart
 Home/Source	 AV
 [≡]	 Text
 P+	 Ch +
 P-	 Ch -
 O)/	 Dual





Original		Replacement		Original	Replacement
	P.Mode		Format		
	S.Mode	 + 	Shift + Dual		
	USB		Pre Ch		
	Play		Play		
	Pause/[≡]		Pause		
	Stop/[≡+]		Stop		
	[≡◆]		3D		
	<</[≡0]		<<		
	<</[≡1]		<<		
	>> /[≡?]		>>		
	>> /[≡x]		>>		
	Red		Red		
	Green		Green		
	Yellow		Yellow		
	Blue		Blue		

