



Original	Replacement	Original	Replacement
	Power		Power
	DBB		Smart / List
	Source		AV / Input / RDS
	Repeat		Green / APP / Repeat
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold
	>>		>> / Preset+
	<<		<< / Preset-
	Prog		TV/Radio /
	Vol+		Vol+
	Vol-		Vol-
	Mute		Mute / Dimmer
	Preset+		Shift + >> / Preset+
	Preset-		Shift + << / Preset-
	Display		Display / Media

