

































































| Original | Replacement | Original | Replacement |
|----------|---|----------|---|
| |  Power | |  0 |
| |  AV / Input / RDS | |  Up |
| |  Menu / Home | |  Down |
| |  Audio / Lang I/II | |  Right |
| |  Display / Media | |  Left |
| |  Setup / OPT / | |  Subtitle / EQ |
| |  TV/Radio / | |  Shift + Power |
| |  1 | |  Stop / Hold |
| |  2 | |  Pause / Step / Freeze |
| |  3 | |  Rec / Rec Mode |
| |  6 | |  << / Tune- |
| |  5 | |  Play / Slow |
| |  4 | |  >> / Tune+ |
| |  7 | |  Shift + Setup / OPT / Tools |
| |  8 | |  Shift + Pause / Step / |
| |  9 | | |
| |  Fav / Marker / PC | | |



| Original | Replacement | |
|-------------|---|-----------------------|
| On/Off |  | Power |
| Update |  | Play / Slow |
| Reveal |  | Pause / Step / Freeze |
| Txt Stop |  | Stop / Hold |
| Info |  | Rec / Rec Mode |
| Subt.List |  | Subtitle / EQ |
| Sleep Timer |  | Picture / Format |
| Return TV |  | Zoom / Size |
| Menu video |  | D.Menu / Top |
| TV/AV |  | AV / Input / RDS |
| Menu |  | Menu / Home |
| Menu Up |  | Up |
| Display |  | Info / Angle |
| Menu Left |  | Left |
| Menu Right |  | Right |
| Menu Down |  | Down |
| Menu audio |  | Display / Media |

| Original | Replacement | |
|--------------|---|-----------------------------|
| 1 |  | 1 |
| 2 |  | 2 |
| 3 |  | 3 |
| 4 |  | 4 |
| 5 |  | 5 |
| 6 |  | 6 |
| 7 |  | 7 |
| 8 |  | 8 |
| 9 |  | 9 |
| 0/10 |  | 0 |
| 2.Fav P/C 2. |  | Fav / Marker / PC |
| Red |  | Red / Netflix / Search |
| Green |  | Green / APP / Repeat |
| Yellow |  | Yellow / YouTube / Repeat |
| Blue |  | Blue / Prime Video / Random |
| | | |
| | | |

