









































































| Original  | Replacement  | Original   | Replacement   |
|---|--|--|---|
|  PWR         |  Power                    |  Yellow/FAV |  Yellow / YouTube / Repeat   |
|  Tv/Rad      |  TV/Radio /               |  Blue/A-Z   |  Blue / Prime Video / Random |
|  Text        |  Text / Goto              |  Menu       |  Menu / Home                 |
|  1           |  1                        |  EPG        |  Guide / EPG / -/-           |
|  2           |  2                        |  Info       |  Info / Angle                |
|  3           |  3                        |  Up         |  Up                          |
|  4           |  4                        |  Down       |  Down                        |
|  5           |  5                        |  Right      |  Right                       |
|  6           |  6                        |  Left       |  Left                        |
|  7           |  7                        |  OK         |  OK                          |
|  8           |  8                        |  Vol+       |  Vol+                        |
|  9         |  9                      |  Vol-     |  Vol-                      |
|  0         |  0                      |  Exit     |  Exit / Cancel / Clear     |
|  Back      |  Back / Return          |  Page+    |  CH+ / Page+               |
|  Mute      |  Mute / Dimmer          |  Page-    |  CH- / Page-               |
|  Red/Opt   |  Red / Netflix / Search |  Pause    |  Pause / Step / Freeze     |
|  Green/AV+ |  Green / APP / Repeat   |  Play     |  Play / Slow               |

| Original  | Replacement   | Original   | Replacement   |
|---|---|--|---|
|  DIMMER MUTE   |    |  TV           |  DVD |
|  SLOW          |    |  SAT          |      |
|  HOLD          |    |  TUNE-        |      |
|  PRESET-       |    |  TITLE        |      |
|  EQ            |    |  SOUND        |      |
|  SUBTITLE      |    |  FORMAT       |      |
|  SLEEP         |    |  PICTURE      |      |
|  RDS           |    |  D.MENU       |      |
|  HOME          |    |  MENU         |      |
|  OK            |    |  CLEAR        |      |
|  EXIT          |    |  CANCEL       |      |
|  VOL+          |    |  SMART       |     |
|  VOL-         |   |  DISPLAY    |    |
|  TV          |  |  1          |    |
|  VIDEO       |  |  2          |    |
|  AUX - HDD   |  |  3          |    |
|  VIDEO       |  |  4          |    |
|  AUX - HDD   |  |  5          |    |
|  VIDEO       |  |  6          |    |
|  AUX - HDD   |  |  7          |    |
|  VIDEO       |  |  8          |    |
|  VIDEO       |  |  9          |    |
|  NETFLIX     |  |  NETFLIX    |    |
|  APP         |  |  APP        |    |
|  YouTube     |  |  YouTube    |    |
|  Prime Video |  |  SEARCH     |    |
|  SEARCH      |  |  REPEAT     |    |
|  REPEAT      |  |  REPEAT A-B |    |
|  REPEAT A-B  |  |  RANDOM     |    |
|  RANDOM      |  |  RANDOM     |    |





|   | Original | Replacement   |
|---|----------|---|
|    | <<       |  << / Tune-        |
|    | Stop     |  Stop / Hold       |
|    | >>       |  >> / Tune+        |
|    | Rec      |  Rec / Rec Mode    |
|    | Slow     |  Shift +<br>Play / |
|    | List     |  Smart / List      |
|    | A-B      |  D.Menu / Top      |
|    | Mark     |  Fav / Marker / PC |
|    | Jump     |  Subtitle / EQ     |
|    | PIP      |  Zoom / Size       |
|   | Swap     |  Setup / OPT /    |
|  | Move     |  Display / Media |
|  | Sleep    |  Sleep / Timer   |
|   |          |   |
|   |          |   |
|   |          |   |

|  | Original | Replacement |
|--|----------|-------------|
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |
|  |          |             |

