








































































Original		Replacement		Original		Replacement	
	Power		Power		Blue / C/S		Shift + Blue / Prime
	Timer		Sleep / Timer		Timer		Shift + Menu /
	Prog+		Shift + Up		Timer Clear		Shift + Exit / Cancel / Clear
	Day+		Shift + Right		Timer On/Off		Shift + Info / Angle
	Start+		Shift + Vol+		SP/LP		Smart / List
	Stop+		Shift + CH+ /		SV/V+		Display / Media
	Text Index		Text / Goto		Return		Back / Return
	Text Reveal		Subtitle / EQ		PAL / SEC		Picture / Format
	Text Size		Zoom / Size		INS / DUB		Sound / Title
	[Stop]		Shift + Stop /		Tip		Menu / Home
	Prog-		Shift + Down		Code		Exit / Cancel / Clear
	Day-		Shift + Left		Counter		I<< / Preset-
	Start-		Shift + Vol-		Reset		>>I / Preset+
	Stop-		Shift + CH- /		Audio		Audio / Lang I/II
	Red / VPS		Shift + Red / Netflix /		SAT		Shift + 0
	Green / ED/EW		Shift + Green / APP /		1		1
	Yellow		Shift + Yellow / YouTube / Repeat		2		2









































































	Original	Replacement		Original	Replacement
	3		3		3
	4		4		4
	5		5		5
	6		6		6
	7		7		7
	8		8		8
	9		9		9
	VPT		Guide / EPG / -/--		VPT
	0		0		0
	AV		AV / Input / RDS		AV
	i		Info / Angle		i
	Up / CH+		Up		Up / CH+
	Up / CH+		CH+ / Page+		Up / CH+
	Right / Vol+		Right		Right / Vol+
	Right / Vol+		Vol+		Right / Vol+
	OK		OK		OK
	Left / Vol-		Vol-		Left / Vol-

	Original	Replacement		Original	Replacement
	Left / Vol-		Left		Down / CH-
	Down / CH-		Down		Down / CH-
	Down / CH-		CH- / Page-		Down / CH-
	Rec		Rec / Rec Mode		Rec
	Stop		Stop / Hold		Stop
	Pause		Pause / Step / Freeze		Pause
	Play		Play / Slow		Play
	Open / Close		Eject / Surround		Open / Close
	<<		<< / Tune-		<<
	>>		>> / Tune+		>>
	Index		Red / Netflix / Search		Index
	Index Mark		Green / APP / Repeat		Index Mark
	Index Erase		Yellow / YouTube / Repeat		Index Erase
	Traking		Blue / Prime Video / Random		Traking








Original		Replacement		Original		Replacement	
	Power		Power		Blue / C/S		Shift + Blue / Prime
	Timer		Sleep / Timer		Timer		Shift + Menu /
	Prog+		Shift + Up		Timer Clear		Shift + Exit / Cancel / Clear
	Day+		Shift + Right		Timer On/Off		Shift + Info / Angle
	Start+		Shift + Vol+		SP/LP		Smart / List
	Stop+		Shift + CH+ /		SV/V+		Display / Media
	Text Index		Text / Goto		Return		Back / Return
	Text Reveal		Subtitle / EQ		PAL / SEC		Picture / Format
	Text Size		Zoom / Size		INS / DUB		Sound / Title
	[Stop]		Shift + Stop /		Tip		Menu / Home
	Prog-		Shift + Down		Code		Exit / Cancel / Clear
	Day-		Shift + Left		Counter		I<< / Preset-
	Start-		Shift + Vol-		Reset		>>I / Preset+
	Stop-		Shift + CH- /		Audio		Audio / Lang I/II
	Red / VPS		Shift + Red / Netflix /		SAT		Shift + 0
	Green / ED/EW		Shift + Green / APP /		1		1
	Yellow		Shift + Yellow / YouTube / Repeat		2		2











































Original		Replacement		Original		Replacement	
	3		3		Left / Vol-		Vol-
	4		4		Down / CH-		Down
	5		5		Down / CH-		CH- / Page-
	6		6		Rec		Rec / Rec Mode
	7		7		Stop		Stop / Hold
	8		8		Pause		Pause / Step / Freeze
	9		9		Play		Play / Slow
	VPT		Guide / EPG / -/--		Open / Close		Eject / Surround
	0		0		<<		<< / Tune-
	AV		AV / Input / RDS		>>		>> / Tune+
	i		Info / Angle		Index		Red / Netflix / Search
	Up / CH+		Up		Index Mark		Green / APP / Repeat
	Up / CH+		CH+ / Page+		Index Erase		Yellow / YouTube / Repeat
	Right / Vol+		Right		Tracking		Blue / Prime Video / Random
	Right / Vol+		Vol+				
	OK		OK				
	Left / Vol-		Left				







Original	Replacement	Original	Replacement
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	AV		AV / Input / RDS
	Up / CH+		Up
	Up / CH+		CH+ / Page+
	Right / Vol+		Right
	Right / Vol+		Vol+
	Left / Vol-		Left

Original	Replacement	Original	Replacement
	Left / Vol-		Vol-
	Down / CH-		Down
	Down / CH-		CH- / Page-

