







































































Original	Replacement
 Power	 Power
 Bright	 Picture / Format
 Text	 Text / Goto
 Rotate	 Smart / List
 Hold	 Stop / Hold
 Subpage	 Setup / OPT /
 Reveal	 D.Menu / Top
 Subtitle	 Subtitle / EQ
 Up	 Up
 End	 Exit / Cancel / Clear
 Left	 Left
 OK	 OK
 Right	 Right
 Audio	 Audio / Lang I/II
 Down	 Down
 Menu	 Menu / Home
 Red	 Red / Netflix / Search

Original	Replacement
 Green	 Green / APP / Repeat
 Yellow	 Yellow / YouTube / Repeat
 Blue	 Blue / Prime Video / Random
 Vol+	 Vol+
 P+	 CH+ / Page+
 Mute	 Mute / Dimmer
 Vol-	 Vol-
 P-	 CH- / Page-
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9





Original Replacement

	Recall		Back / Return
	0		0
	Input		AV / Input / RDS

Original Replacement



Mandis

Mandis