



Original	Replacement
Sleep	Sleep / Timer
Power	Power
Scene 1	1
Scene 2	2
Scene 3	3
Scene 4	4
Straight	Audio / Lang I/II
Pure Direct	Subtitle / EQ
Enhancer	Text / Goto
Sur.Decode	Picture / Format
< Program	CH- / Page-
Program >	CH+ / Page+
Input Up	Shift + Up
Tuner	6
Volume+	Vol+
USB	8
Input Down	Shift + Down

Original	Replacement
NET	Fav / Marker / PC
Volume-	Vol-
Bluetooth	9
Mute	Mute / Dimmer
Setup	Setup / OPT /
Up	Up
Option	Shift + Setup / OPT / Tools
Left	Left
Enter	OK
Right	Right
Return	Back / Return
Down	Down
Display	Display / Media
Top Menu	D.Menu / Top
Home	Menu / Home
Pop-Up/Menu	Shift + Menu /
Red	Red / Netflix / Search





Original	Replacement
	Green / APP / Repeat
	Yellow / YouTube / Repeat
	Blue / Prime Video / Random
	Fast Reverse / Preset-
	MEMORY / Play / Slow
	Fast Forward / Preset+
	TUNING / Fast Reverse
	MODE / Stop / Hold
	BAND / Pause / Step / Freeze
	TUNING / Fast Forward
	Shift + Preset- / Preset-
	Shift + Preset+ / Preset+

Original	Replacement





Original	Replacement
Sleep	Sleep / Timer
Power	Power
Scene 1	1
Scene 2	2
Scene 3	3
Scene 4	4
Input Up	+ Shift + Up
Tuner	6
Volume+	Vol+
USB	8
Input Down	+ Shift + Down
NET	Fav / Marker / PC
Volume-	Vol-
Bluetooth	9
Mute	Mute / Dimmer
Up	Up
Left	Left

Original	Replacement
Enter	OK
Right	Right
Return	Back / Return
Down	Down
Display	Display / Media
Top Menu	D.Menu / Top
Home	Menu / Home
Pop-Up/Menu	+ Shift + Menu /
Red	Red / Netflix / Search
Green	Green / APP / Repeat
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
I<<	I<< / Preset-
Play/Memory	Play / Slow
>>I	>>I / Preset+
<< Tuning	<< / Tune-
Stop/Mode	Stop / Hold





	Original	Replacement		Original	Replacement
	Pause/Band	Pause / Step / Freeze			
	Tuning >>	>> / Tune+			
	< Preset	Shift + << / Preset-			
	Preset >	Shift + >> / Preset+			

