





























































Original		Replacement		Original		Replacement	
	Power		Power		0		0
	Volume Up		Vol +		CD		Yellow
	Volume Down		Vol -		+10		Guide
	Sleep		Sleep		Tape		Blue
	Timer Standby		Shift + Power		Video1/DAT		Smart
	Band		Green		Video 2/AUX		Media
	Mono Tuner		TV/R		DSP		3D
	Mode Display		Info		PRGM/Test		Menu
	1		1		GEQ		Back
	2		2		Manual/Mode		Pre Ch
	3		3		Mute		Mute
	4		4		Volume Select		Dual
	5		5		Up		Up
	6		6		Down		Down
	7		7		Right		Right
	8		8		Left		Left
	9		9		Direct		Options








Original	Replacement
 Power	 Power
 Volume Up	 Vol +
 Volume Down	 Vol -
 Mute	 Mute
 Band	 Green
 CD	 Yellow
 Tape	 Blue
 Video1/DAT	 Smart
 Video2/AUX	 Media
 Repeat	 Text
 Random	 AV
 Disc Skip	 Info
 Disc Direct Play 1	 Shift + 1
 Disc Direct Play 2	 Shift + 2
 Disc Direct Play 3	 Shift + 3
 1	 1
 2	 2




















Original	Replacement
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 +10	 Guide
 PRGM CD	 Menu
 Play/Pause	 Play
 Stop/Clear	 Stop
 Search/Check	 >>
 I<<	 I<<
 Edit AI	 Format
 Edit PRGM	 3D
 <> Deck 1	 Pause







Original	Replacement
 Power	 Power
 Volume Up	 Vol +
 Volume Down	 Vol -
 Mute	 Mute
 Band	 Green
 CD	 Yellow
 Tape	 Blue
 Video1/DAT	 Smart
 Video2/AUX	 Media
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8

Original	Replacement
 9	 9
 0	 0
 +10	 Guide
 PRGM DAT	 Menu
 <> Deck 2	 Play
 Stop Deck 2	 Stop
 >> Deck 2	 >>
 << Deck 2	 <<
 Rec/Rec Mute	 Rec
 Pause	 Pause

