Mandis shop

RE9220- 1

Original		Replacement	
	Power		Power
	Night	CLEAR EXIT	Exit
	Mute	MUTE	Mute
OPT 1	OPT 1	1	1
AUX 2	AUX 2	2	2
	Bluetooth	HOME SMART	Smart
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
VOICE +	Voice+		Up
VOICE −	Voice-		Down
BASS +	Bass+	CH +	Ch +
BASS −	Bass-	CH −	Ch -
	I<		I<<
	Play	PLAY MODE	Play
	>I		>>I
MOVIE	Movie	A	Red
GAME	Game	B	Green

Original		Replacement	
MUSIC	Music	C	Yellow