




























Original	Replacement	Original	Replacement
	Power		Power
	Red		Red
	Green		Green
	Yellow		Yellow
	Blue		Blue
	White	 + 	Shift + Blue
	Guide		Guide
	[⊖]	 + 	Shift + Power
	[?]		Smart
	[↕]		3D
	Text		Text
	□→		AV
	□→		Exit
	Up		Up
	Left		Left
	OK		Ok
	Right		Right
	Down		Down
	Vol+		Vol +
	Vol-		Vol -
	P+		Ch +
	P-		Ch -
	Mute		Mute
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	[i+]		Info





Original	Replacement	Original	Replacement
P<P / -/	Pre Ch		
I-II	Shift + Dual		
	Stop		
[1 2]	Media		
[♦]	TV/R		
Smart Audio	Dual		
Smart Picture	Format		
[[<>]]	Shift + Format		
Rec DNR	Rec		

Original	Replacement

