














































| Original | Replacement |
|---|---|
|  Power |  Power |
|  O/D/N |  D.Menu / Top |
|  Sound / Title |  Sound / Title |
|  Shift + Back / Return |  Shift + Back / Return |
|  Source |  AV / Input / RDS |
|  Info / Angle |  Info / Angle |
|  Audio / Lang I/II |  Audio / Lang I/II |
|  Shift + Text / Goto |  Shift + Text / Goto |
|  Red / Netflix / Search |  Red / Netflix / Search |
|  Text / Goto |  Text / Goto |
|  Green / APP / Repeat |  Green / APP / Repeat |
|  Yellow / YouTube / Repeat |  Yellow / YouTube / Repeat |
|  Blue / Prime Video / Random |  Blue / Prime Video / Random |
|  Menu / Home |  Menu / Home |
|  Back / Return |  Back / Return |
|  CH+ / Page+ |  CH+ / Page+ |
|  Up |  Up |

| Original | Replacement |
|---|---|
|  Right |  Right |
|  Vol+ |  Vol+ |
|  Left |  Left |
|  Vol- |  Vol- |
|  OK |  OK |
|  CH- / Page- |  CH- / Page- |
|  Down |  Down |
|  Shift + Power |  Shift + Power |
|  Play / Slow |  Play / Slow |
|  Mute / Dimmer |  Mute / Dimmer |
|  TUNE- << / Tune- |  TUNE- << / Tune- |
|  Pause / Step / Freeze |  Pause / Step / Freeze |
|  TUNE+ >> / Tune+ |  TUNE+ >> / Tune+ |
|  Shift + Pause / Step / Freeze |  Shift + Pause / Step / Freeze |
|  I<< / Preset- |  I<< / Preset- |
|  Stop / Hold |  Stop / Hold |
|  I>> / Preset+ |  I>> / Preset+ |



