



































































Original	Replacement
 Power	 Power
 V-Format	 Format
 Mute	 Mute
 F1	 Shift + 1
 F2	 Shift + 2
 TV/AV	 AV
 Sleep	 Sleep
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0

Original	Replacement
 Fav	 Pre Ch
 Pause	 Pause
 Page+	 Shift + Ch +
 Page-	 Shift + Ch -
 PR-	 Back
 PR+	 Ch +
 PR+	 Up
 PR-	 Ch -
 PR-	 Down
 Right / Vol+	 Vol +
 Right / Vol+	 Right
 Left / Vol-	 Vol -
 Left / Vol-	 Left
 OK / List	 Ok
 OK / List	 List
 Menu	 Menu
 Exit	 Exit





Original	Replacement
 Info	 Info
 EPG	 Guide
 Red / Find	 Red
 TV/Radio	 TV/R
 Red / Find	 Shift + TV/R
 Green / TXT	 Green
 Green / TXT	 Text
 Yellow / Subtitle	 Yellow
 Yellow / Subtitle	 Subt
 Blue / Audio	 Blue
 Blue / Audio	 Dual
 Record	 Rec
 Play	 Play
 Stop	 Stop
 Shift	 Smart
 << Fast	 <<
 Fast >>	 >>

Original	Replacement
 < Slow	 I<<
 Slow >	 >>I

