Mandis shop

REMCON278

Original		Replacement	
	Power		Power
	TV / Radio	SEARCH TV/R	TV/R
	Mute	MUTE	Mute
	i	DISPLAY INFO	Info
	ALT	RETURN BACK	Back
	M/A	HOME SMART	Smart
	Teletext	REPEAT TEXT	Text
	Exit	CLEAR EXIT	Exit
	Menu	TOP MENU MENU	Menu
	FAV	FAV PRE-CH	Pre Ch
	P/L	APP MEDIA	Media
	Up		Up
	Left		Left
	OK	OK	Ok
	Right		Right
	Down		Down
	Vol +	VOL +	Vol +

Original		Replacement	
	Vol -	VOL -	Vol -
PG+	PG+	CH +	Ch +
PG-	PG-	CH -	Ch -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

https://remcontrols.dk/1063-881-replacement-remcontrol-for-REMCON278.htm