



Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Tv/Radio		TV/Radio /
	0		0
	←PR		Back / Return
	EPG		Guide / EPG / -/--
	Up		Up
	PR+		CH+ / Page+
	Menu		Menu / Home
	Vol-		Vol-
	Left		Left
	OK/List		OK
	Right		Right
	Vol+		Vol+
	Info		Info / Angle
	PR-		CH- / Page-
	Down		Down
	Exit		Exit / Cancel / Clear
	Red		Red / Netflix / Search
	Audio		Audio / Lang I/II
	↑		>> / Tune+
	Yellow		Yellow / YouTube / Repeat
	[...]		Subtitle / EQ
	↓		<< / Tune-
	Blue		Blue / Prime Video / Random



