







































































Original		Replacement		Original		Replacement	
	Standby		Power		Open/Close		Eject
	DVD		Smart		Tv/Video		TV/R
	HDD		Media		Guide		Guide
	1		1		Info		Info
	2		2		Enter		Ok
	3		3		Up		Up
	4		4		Down		Down
	5		5		Right		Right
	6		6		Left		Left
	7		7		Menu		Menu
	8		8		Top Menu		Shift + Menu
	9		9		Cancel		Exit
	0		0		Navigation		List
	Vol+ Tv		Vol +		Return		Back
	Vol- Tv		Vol -		Edit		Text
	PR+		Ch +		Prog		Sleep
	PR-		Ch -		I<</Day(-)		I<<





Original		Replacement		Original		Replacement	
	>> /Day(+)		>>		Rec		Rec
	Play		Play		Angle/Live Check		D. Menu
	Stop/Clear		Stop		Standby Tv		Shift + Power
	Pause		Pause		Tv/Video Tv		Shift + TV/R
	<</Slow-		<<		Live		3D
	>>/Slow+		>>		?/Help		Pre Ch
	Memo/Mark		AV		PR+ Tv		Shift + Ch +
	Red/Display		Red		PR- Tv		Shift + Ch -
	Green/On		Green		Prog Tv		Shift + Sleep
	Yellow/Recall		Yellow		1 Tv		Shift + 1
	Blue/→		Blue		2 Tv		Shift + 2
	Audio		Dual		3 Tv		Shift + 3
	Subtitle/VPS/PDC/Timer		Subt		4 Tv		Shift + 4
	Format/Output		Format		5 Tv		Shift + 5
	Dubbing		Shift + Options		6 Tv		Shift + 6
	Setup		Options		7 Tv		Shift + 7
	Rec		Shift + Rec		8 Tv		Shift + 8



Mode/Remain



Original		Replacement		Original		Replacement	
	9 Tv	 + 	Shift + 9				
	0 Tv	 + 	Shift + 0				
	Cancel Tv	 + 	Shift + Exit				
	Tv Mute		Mute				
	Guide Tv	 + 	Shift + Guide				

