
























































Original	Replacement
 Power	 Power
 Tv / Rad	 TV/R
 Source	 AV
 Settings	 D. Menu
 Live Zoom	 Eject
 Subtitle	 Subt
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 List	 List

Original	Replacement
 Guide	 Guide
 Vol+	 Vol +
 Vol-	 Vol -
 Info	 Info
 Search	 Shift + TV/R
 Mute	 Mute
 P/Page+	 Ch +
 P/Page-	 Ch -
 Recent	 Pre Ch
 Home	 Smart
 Live Menu	 Menu
 Back	 Back
 Exit	 Exit
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left





Original	Replacement	Original	Replacement
 OK	 Ok		
 Text	 Text		
 T.Opt	 Options		
 AD	 Shift + Subt		
 APP/*	 Media		
 Stop/Live Tv	 Stop		
 <<	 <<		
 Play	 Play		
 Pause	 Pause		
 >>	 >>		
 Red	 Red		
 Green	 Green		
 Yellow	 Yellow		
 Blue	 Blue		

