


































Original	Replacement
 Power	 Power
 Open/Close	 Eject
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 F	 Menu
 Preset/Folder Up	 Ch +
 Preset/Folder	 Ch -
 Jukebox/Memor	 Smart
 Auto Dj	 Options
 Delete	 Exit
 Repeat	 Text
 >>I	 >>I
 Tuning+	 Right
 Tuning-	 Left
 I<<	 I<<
 Play	 Play

Original	Replacement
 Pause	 Pause
 Stop	 Stop
 Sound Effect	 Dual
 Region EQ	 TV/R
 Info/Sleep	 Info
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Clock	 Shift + AV
 Alarm	 Media



