



Original	Replacement
Power	Power
Sound Mode	Sound / Title
Dimmer/Sleep	Smart / List
Mute	Mute / Dimmer
HDMI 1	Setup / OPT /
Portable	Subtitle / EQ
Vol+	Vol+
HDMI 2	Menu / Home
Optical	Zoom / Size
Vol-	Vol-
Coaxial	Sleep / Timer
USB Random	Up
Tv Speaker/On/Off	Shift + Smart / List
I<<	I<< / Preset-
I<<	<< / Tune-
Stop	Stop / Hold
Stop	OK

Original	Replacement
>>I	>>I / Preset+
>>I	>> / Tune+
Display	Display / Media
Play/Pause	Play / Slow
Play	Down
Pause	Pause / Step / Freeze
USB/Repeat	Green / APP / Repeat

