







| Original | Replacement |
|--|---|
|  Power |  Power |
|  Repeat |  Green / APP / Repeat |
|  A-B |  Yellow / YouTube / Repeat |
|  Open/Close |  Eject / Surround |
|  N/P |  Blue / Prime Video / Random |
|  Subtitle |  Subtitle / EQ |
|  Angle |  Info / Angle |
|  Language |  Audio / Lang I/II |
|  Setup |  Setup / OPT / |
|  Title |  Sound / Title |
|  1 |  1 |
|  2 |  2 |
|  3 |  3 |
|  4 |  4 |
|  5 |  5 |
|  6 |  6 |
|  7 |  7 |

| Original | Replacement |
|--|---|
|  8 |  8 |
|  9 |  9 |
|  Time |  Sleep / Timer |
|  0 |  0 |
|  10+ |  Guide / EPG / -/- |
|  Up |  Up |
|  PBC |  D.Menu / Top |
|  Down |  Down |
|  Right |  Right |
|  Left |  Left |
|  Enter |  OK |
|  Menu |  Menu / Home |
|  Vol+ |  Vol+ |
|  Vol- |  Vol- |
|  Zoom |  Zoom / Size |
|  Return |  Back / Return |
|  L/R |  Smart / List |





| Original | Replacement |
|----------|------------------------|
| | Shift + Pause / Step / |
| | Shift + Play / |
| | TV/Radio / |
| | Exit / Cancel / Clear |
| | Mute / Dimmer |
| | Display / Media |
| | I<< / Preset- |
| | >>I / Preset+ |
| | << / Tune- |
| | >> / Tune+ |
| | Picture / Format |
| | Stop / Hold |
| | Play / Slow |
| | Pause / Step / Freeze |
| | |
| | |
| | |

| Original | Replacement |
|----------|-------------|
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |
| | |

