




Original	Replacement	Original	Replacement
	Power		Red
	TXT		Green
	EPG		Yellow
	Input		Blue
	Menu		Vol +
	[>]		Vol -
	Lang		Mute
	Subt		[+]
	Exit		Ch +
	Q.Menu		Ch -
	Back		1
	Up		2
	Down		3
	Right		4
	Left		5
	OK		6
			7



