







































































Original	Replacement	Original	Replacement
 Power	 Power	 Menu/Browse	 Menu / Home
 Source	 AV / Input / RDS	 Exit	 Exit / Cancel / Clear
 Teletext	 Text / Goto	 Down	 Down
 [112]	 Zoom / Size	 Option	 Setup / OPT /
 Subtitle	 Subtitle / EQ	 Vol+	 Vol+
 [<>]	 Picture / Format	 PR+	 CH+ / Page+
 Red/Demo	 Red / Netflix / Search	 Vol-	 Vol-
 Green	 Green / APP / Repeat	 Mute	 Mute / Dimmer
 Yellow	 Yellow / YouTube / Repeat	 PR-	 CH- / Page-
 Blue	 Blue / Prime Video / Random	 1	 1
 Guide	 Guide / EPG / -/--	 2	 2
 Info	 Info / Angle	 3	 3
 Up	 Up	 4	 4
 Left	 Left	 5	 5
 Back	 Back / Return	 6	 6
 OK	 OK	 7	 7
 Right	 Right	 8	 8





Original		Replacement		Original		Replacement	
9	9	BLUETOOTH 9	9				
MHEG CANCEL	MHEG/Cancel	SHIFT + CLEAR EXIT CANCEL	Shift + Exit / Cancel / Clear				
0	0	HDMI - BAT 0	0				
P=P	P=P	PC FAV MARKER	Fav / Marker / PC				
AMBILIGHT	Ambilight	MEDIA DISPLAY	Display / Media				
MODE	Mode	LIST SMART	Smart / List				

