







































































Original		Replacement		Original		Replacement	
	Power		Power		Green		Green
	Rec		Rec		Yellow		Yellow
	Pause		Pause		Blue		Blue
	Stop		Stop		Info		Info
	Play		Play		Options		Options
	<<		<<		Up		Up
	>>		>>		Down		Down
	Settings		Pre Ch		Right		Right
	≡/List		List		Left		Left
	Ambilight		Media		OK		Ok
	Tv Guide		Guide		Back		Back
	Search		TV/R		Home		Smart
	Top Picks		D. Menu		Vol+		Vol +
	Sources		AV		Vol-		Vol -
	Tv Menu		Menu		CH+		Ch +
	TV/Exit		Exit		CH-		Ch -
	Red		Red		Netflix		Shift + Media



