







































































Original	Replacement	Original	Replacement
 Power	 Power	 Blue/[]	 Blue
 Vol+	 Vol +	 Info	 Info
 Vol-	 Vol -	 Text	 Text
 PR+	 Ch +	 1	 1
 PR-	 Ch -	 2	 2
 Mute	 Mute	 3	 3
 Menu	 Menu	 4	 4
 Exit	 Exit	 5	 5
 Back	 Back	 6	 6
 OK	 Ok	 7	 7
 Up	 Up	 8	 8
 Down	 Down	 9	 9
 Right/Zoom+	 Right	 0/-/--	 0
 Left/Zoom-	 Left	 AV	 AV
 Red/[o]	 Red	 SP/LP	 Media
 Green/Timer/List	 Green	 Play	 Play
 Yellow	 Yellow	 >>	 >>






































































	Original	Replacement	Original	Replacement
	REV	<<	<<	<<
	STOP	Stop	Stop	Stop
	PAUSE	Pause	Pause	Pause
	REC	Rec	REC MODE	Rec
	MARK	Mark	ECO 3D	3D
	0000	0000	-/-- GUIDE	Guide































































Original	Replacement	Original	Replacement
 Power	 Power	 Blue/[]	 Blue
 Vol+	 Vol +	 Info	 Info
 Vol-	 Vol -	 Text	 Text
 Mute	 Mute	 Play	 Play
 PR+	 Ch +	 Stop	 Stop
 PR-	 Ch -	 Rec	 Rec
 Exit	 Exit	 Pause	 Pause
 Menu	 Menu	 >>	 >>
 Back	 Back	 <<	 <<
 Up	 Up	 1	 1
 Down	 Down	 2	 2
 Right/Zoom+	 Right	 3	 3
 Left/Zoom-	 Left	 4	 4
 OK	 Ok	 5	 5
 Red/[o]	 Red	 6	 6
 Green/Timer/List	 Green	 7	 7
 Yellow	 Yellow	 8	 8





Original	Replacement	Original	Replacement
	 Power		 Blue/[]
	 Vol +		 Info
	 Vol -		 Text
	 Mute		 1
	 Ch +		 2
	 Ch -		 3
	 Menu		 4
	 Exit		 5
	 Back		 6
	 Up		 7
	 Down		 8
	 Right		 9
	 Left		 0
	 Ok		 AV
	 Red		 Media
	 Green		 Play
	 Yellow		 Stop



