



































































Original	Replacement	Original	Replacement
 Power	 Power	 Tv	 TV/Radio /
 1	 1	 2	 2
 3	 3	 4	 4
 5	 5	 6	 6
 7	 7	 8	 8
 9	 9	 FAV.CH	 Fav / Marker / PC
 0	 0	 PRE CH	 Back / Return
 Vol+	 Vol+	 Mute	 Mute / Dimmer
 PR+	 CH+ / Page+		

Original	Replacement	Original	Replacement
 Vol-	 Vol-	 Source	 AV / Input / RDS
 PR-	 CH- / Page-	 Info	 Info / Angle
 Menu	 Menu / Home	 Guide	 Guide / EPG / -/-
 Tools	 Setup / OPT /	 Up	 Up
 Return	 Shift + Back / Return	 Left	 Left
 Enter	 OK	 Right	 Right
 CH LIST	 Smart / List	 Down	 Down
 Exit	 Exit / Cancel / Clear	 Red	 Red / Netflix / Search
 Green	 Green / APP / Repeat		





Original	Replacement	Original	Replacement
 Yellow	 Yellow / YouTube / Repeat		
 Blue	 Blue / Prime Video / Random		
 TTX/MIX	 Text / Goto		
 Media P	 Display / Media		
 P SIZE	 Zoom / Size		
 Dual	 Audio / Lang I/II		
 AD	 Eject / Surround		
 SUBT	 Subtitle / EQ		
 <<	 << / Tune-		
 Pause	 Pause / Step / Freeze		
 >>	 >> / Tune+		
 Rec	 Rec / Rec Mode		
 Play	 Play / Slow		
 Stop	 Stop / Hold		

