



Original	Replacement	Original	Replacement
Power	Power	PC	Media
Source	AV	Mute	Mute
1	1	Vol+	Vol +
2	2	Vol-	Vol -
3	3	P+	Ch +
4	4	P-	Ch -
5	5	Menu	Menu
6	6	Exit	Exit
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
-/--	GUIDE	Enter	Ok
PRE-CH	Pre Ch	[≡+]/PIP	3D
TV	TV/R	[≡?]/Info	Info
CH.MGR	Back	[≡]/[/≡]/TTX/MIX	Text
Sleep	Sleep	Red/-I/I-/P.Mode	Red

Original	Replacement	Original	Replacement
Power	Power	PC	Media
Source	AV	Mute	Mute
1	1	Vol+	Vol +
2	2	Vol-	Vol -
3	3	P+	Ch +
4	4	P-	Ch -
5	5	Menu	Menu
6	6	Exit	Exit
7	7	Up	Up
8	8	Down	Down
9	9	Right	Right
0	0	Left	Left
-/--	GUIDE	Enter	Ok
PRE-CH	Pre Ch	[≡+]/PIP	3D
TV	TV/R	[≡?]/Info	Info
CH.MGR	Back	[≡]/[/≡]/TTX/MIX	Text
Sleep	Sleep	Red/-I/I-/P.Mode	Red



