












































































	Original	Replacement		Original	Replacement
	Power		Power		[i+]/[?]
	Source		AV		Return
	[+]		3D		Zoom
	I<<		I<<		Menu
	>>I		>>I		Up
	<<		<<		Down
	>>		>>		Right
	Stop		Stop		Left
	Play		Play		OK
	Pause		Pause		1
	Red		Red		2
	Green		Green		3
	Yellow		Yellow		4
	Blue		Blue		5
	Repeat		Shift + Text		6
	Audio		Dual		7
	Guide		Guide		8





	Original	Replacement		Original	Replacement
	9	 9			
	0	 0			
	FAV	 +  Shift + Pre Ch			
	[≡]	 Text			
	[...]	 Subt			
	Vol+	 Vol +			
	Vol-	 Vol -			
	Mute	 Mute			
	Prog+	 Ch +			
	Prog-	 Ch -			
	Recall	 Pre Ch			

