



























































Original	Replacement	Original	Replacement
	Power		Salir
	Info		Entrada
	Mute		Up
	1		Down
	2		Right
	3		Left
	4		OK
	5		Vol +
	6		Vol -
	7		P+
	8		P-
	9		Red
	0		Green
	FAV		Yellow
	Recall		Blue
	Menú		Imagen
	EPG		Sonido
	Power		Exit
	Info		AV
	Mute		Up
	1		Down
	2		Right
	3		Left
	4		Ok
	5		Vol +
	6		Vol -
	7		Ch +
	8		Ch -
	9		Red
	0		Green
	Pre Ch		Yellow
	Back		Blue
	Menu		Format
	Guide		Dual





	Original	Replacement	Original	Replacement
	Sleep	 Sleep		
	Tamaño	 3D		
	Grabar	 Rec		
	List.Grab	 List		
	TXT	 Text		
	USB	 Media		
	Play	 Play		
	Pause	 Pause		
	Stop	 Stop		
	I<<	 I<<		
	>>I	 >>I		
	<<	 <<		
	>>	 >>		
	Audio	 +  Shift + Dual		
	Subtitulo	 Subt		

