































Original	Replacement
 Mute	 Mute / Dimmer
 A/B	 Shift + Yellow / YouTube /
 A/B	 Display / Media
 Shift + EPG / -/--	 Shift + Guide / EPG / -/--
 Power	 Power
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 EPG	 Guide / EPG / -/--
 0	 0
 OK	 OK

Original	Replacement
 Up / P+	 CH+ / Page+
 Up / P+	 Up
 Left / Vol-	 Left
 Left / Vol-	 Vol-
 Right / Vol+	 Right
 Right / Vol+	 Vol+
 TV / Radio	 TV/Radio /
 Down / P-	 CH- / Page-
 Down / P-	 Down
 Menu	 Menu / Home
 Red / PIP	 Red / Netflix / Search
 Green / Zoom	 Green / APP / Repeat
 Green / Zoom	 Zoom / Size
 Yellow / ?	 Yellow / YouTube / Repeat
 Blue / Info	 Info / Angle
 Blue / Info	 Blue / Prime Video / Random
 Recall	 Back / Return



