








































Original	Replacement
 Power	 Power
 Mute	 Mute / Dimmer
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 Audio	 Audio / Lang I/II
 0	 0
 Recall	 Back / Return
 Aspect	 Shift + Picture / Format
 Sound	 Sound / Title
 APP	 Display / Media

Original	Replacement
 Vol+	 Vol+
 Home	 Shift + Menu /
 Home	 D.Menu / Top
 CH+	 CH+ / Page+
 Vol-	 Vol-
 EPG	 Guide / EPG / -/-
 CH-	 CH- / Page-
 Picture	 Picture / Format
 TV	 Shift + 1
 TV	 TV/Radio /
 USB	 Shift + 8
 Menu	 Menu / Home
 Up	 Up
 Source	 AV / Input / RDS
 Left	 Left
 OK	 OK
 Right	 Right









































































Original	Replacement
Exit	Exit / Cancel / Clear
Down	Down
Info / Text Index	Info / Angle
Red / <<<	<<< / Tune-
Red / <<<	Red / Netflix / Search
Green / >>>	>>> / Tune+
Green / >>>	Green / APP / Repeat
Yellow / I<<<	I<<< / Preset-
Yellow / I<<<	Yellow / YouTube / Repeat
Blue / >>>I	>>>I / Preset+
Blue / >>>I	Blue / Prime Video / Random
Play / Pause	Play / Slow
Stop	Stop / Hold
Repeat	Shift + Green / APP /
Text	Text / Goto
Text Hold	Shift + Stop /
Text Cancel	Shift + Exit / Cancel / Clear

Original	Replacement
Text Subpage	Eject / Surround
Text Reveal	Shift + Play /
Text Size	Zoom / Size
FAV	Fav / Marker / PC
SUB	Subtitle / EQ
List	Smart / List





Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Audio		Audio / Lang I/II
	0		0
	Recall		Back / Return
	Aspect		Setup / OPT /
	Aspect		Shift + Picture / Format
	Sound		Sound / Title
	APP		Display / Media
	Vol+		Vol+
	Home		Shift + Menu /
	Home		D.Menu / Top
	CH+		CH+ / Page+
	Vol-		Vol-
	EPG		Guide / EPG / -/-
	CH-		CH- / Page-
	Picture		Picture / Format
	TV		TV/Radio /
	TV		Shift + 1
	USB		Shift + 8
	Menu		Menu / Home
	Up		Up
	Source		AV / Input / RDS
	Left		Left
	OK		OK





Original	Replacement
Right	Right
Exit	Exit / Cancel / Clear
Down	Down
Info / Text Index	Info / Angle
Red / <<	<< / Tune-
Red / <<	Red / Netflix / Search
Green / >>	>> / Tune+
Green / >>	Green / APP / Repeat
Yellow / I<<	I<< / Preset-
Yellow / I<<	Yellow / YouTube / Repeat
Blue / >>I	>>I / Preset+
Blue / >>I	Blue / Prime Video / Random
Play/Pause	Play / Slow
Stop	Stop / Hold
Repeat	Shift + Green / APP /
Text	Text / Goto
Text Hold	Shift + Stop /

Hold

Original	Replacement
Text Cancel	Shift + Exit / Cancel / Clear
Text Subpage	Eject / Surround
Text Reveal	Shift + Play /
Text Size	Zoom / Size
Fav	Fav / Marker / PC
SUB	Subtitle / EQ
List	Smart / List

