











































Original	Replacement
 Power	 Power
 Library	 Smart
 Mute	 Mute
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Rec	 Rec
 Last	 Pre Ch
 I<	 I<<
 <<	 <<

Original	Replacement
 Play	 Play
 Stop	 Stop
 Pause	 Pause
 >>	 >>
 >	 >>
 Up	 Up
 Left	 Left
 OK	 Ok
 Right	 Right
 Down	 Down
 Vol +	 Vol +
 Vol -	 Vol -
 Guide	 Guide
 Menu	 Menu
 Prog +	 Ch +
 Prog -	 Ch -
 Back	 Back





Original		Replacement		Original		Replacement	
	Info		Info				
	Text		Text				
	Exit		Exit				
	Red		Red				
	Green		Green				
	Yellow		Yellow				
	Blue		Blue				
	AD		Shift + Subt				
	Subt		Subt				
	Audio		Dual				
	A/V		AV				
	HDMI		Media				
	Wide		Format				

