Originalfernbedienung		Ersatzfernbedienung	
OPEN/CLOSE	Open/Close	SURROUND	Eject / Surround
POWER	Power		Power
TV/VCR	Tv/VCR	RDS AV INPUT	AV / Input / RDS
VCR	VCR	SHIFT + VIDEO 4	Shift + 4
DVD	DVD	SHIFT + DVD 2	Shift + 2
CLOCK/COUNTER	Clock Counter	ANGLE INFO	Info / Angle
PROGRAM	Program	PROGRAM TV/RADIO	TV/Radio /
ONE TOUCH REPEAT	One Touch	APP REPEAT	Green / APP / Repeat
INSTANT SKIP	Instant Skip	GOTO TEXT	Text / Goto
VCR MENU SETUP	Setup/VCR	OPT-TOOLS SETUP	Setup / OPT /
ZOOM	Zoom	SIZE ZOOM	Zoom / Size
SLOW	I > Slow	Prime Video RANDOM	Blue / Prime Video / Random
TOP MENU	Top Menu	TOP MENU D.MENU	D.Menu / Top
CH+	Up		Up
CH+	CH+	CH PAGE	CH+ / Page+
DVD MENU	DVD Menu	HOME MENU	Menu / Home
SET-	Left/Set-		Left

Originalfernbedienung		Ersatzfernbedienung	
ENTER	Enter	OK	OK
SET+	Right/Set+		Right
CANCEL CLEAR	Clear/Cancel	CLEAR EXIT CANCEL	Exit / Cancel / Clear
CH-	CH-	CH PAGE	CH- / Page-
CH-	Down		Down
RETURN	Return	RETURN BACK	Back / Return
STOP	Stop	HOLD	Stop / Hold
PAUSE/STEP	Pause/Step	STEP-FREEZE	Pause / Step / Freeze
PLAY	Play	SLOW	Play / Slow
INDEX-SKIP-	I<< Skip/Index-	PRESET-	I<< / Preset-
REV	<<	TUNE-	<< / Tune-
FWD	>>	TUNE+	>> / Tune+
INDEX+SKIP+	Skip	PRESET+	>>I / Preset+
REC/OTR	Rec/OTR	REC MODE	Rec / Rec Mode
TIMER REC	Timer Rec	TIMER SLEEP	Sleep / Timer
SP/LP PLAY MODE	Play	NETFLIX SEARCH	Red / Netflix / Search
A-B RPT	A-B RPT	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
1	1	TV 1	1		
2	2	DVD 2	2		
3	3	CD-STB 3	3		
CALL DISPLAY	Display/Call	MEDIA DISPLAY	Display / Media		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
ZERO RETURN JUMP	Jump/Zero Return	-/-- GUIDE EPG	Guide / EPG / -/--		
7	7	AUX-HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
●AUX 0	0/AUX	HDMI-SAT 0	0		
COUNTER RESET ANGLE	Camera/Angle/Counter Reset	FORMAT PICTURE	Picture / Format		
ATR SUBTITLE	[...]/Subtitle/A	EQ SUBTITLE	Subtitle / EQ		
AUDIO SELECT AUDIO	O))/Audio/Audio Select	LANG I/II AUDIO	Audio / Lang I/II		
MARKER	Marker	PC FAV MARKER	Fav / Marker / PC		