Mandis shop

CLEANFAST



Original		Replacement		Original	Replacement
II	II		Power		
SPOT	Spot	1 SETUP	1 / Setup		
CLEAN	Clean	2 MENU	2 / Menu		
MAX	Max	3 EXIT	3 / Exit		
FORWARD	Forward		Up		
BACK	Back		Down		
RIGHT	Right		Right		
LEFT	Left		Left		

https://remotecontrols.dk/en/SuperChef/1038414-82980-replacement-remote-control-for-SuperChef-Clean-Fast.html