Mandis shop

TRAVELHD

Original	Replacement	Original	Replacement
Power	Power	>>I/Next	>>I
Home	Smart	Zoom	Eject
X	AV	Vol+	Vol +
Menu	Menu	Vol-	Vol -
Edit	Exit	Mute	Mute
Up	Up		
Down	Down		
Right	Right		
Left	Left		
Enter	Ok		
Info	Info		
Play	Play		
Pause	Pause		
Stop	Stop		
<</FR	<<		
>>/FF	>>		
I<</Prev	I<<		

https://remotecontrols.dk/en/WE/1058570-90734-replacement-remote-control-for-WE-Travel-HD-1T-Travel-HD.html