Mandis shop

Yamaha CDX7

Original	Replacement	Original	Replacement
Open/Close	Eject	Repeat	Text
Pure Direct	Smart	Program	Sleep
CD/USB	Media	Random	3D
Dimmer	TV/R	A/B	Guide
Display	Info	<<	<<
1	1	>>	>>
2	2	Pause	Pause
3	3	Stop	Stop
4	4	>>I	>>I
5	5	I <<	I <<
6	6	Play	Play
7	7		
8	8		
9	9		
0	0		
Enter	Ok		
Clear	Exit		

https://remotes.com/Yamaha/1625-802-replacement-remote-control-for-Yamaha-CDX7-WQ06880.htm