Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
Lang	Dual
TXT	Text
Vol+	Vol +
Vol-	Vol -
Mute	Mute
Source	AV

Original	Replacement
P+	Ch +
P-	Ch -
Home	Smart
[G]	Guide
i	Info
Back	Back
Exit	Exit
Up	Up
Down	Down
Right	Right
Left	Left
OK	Ok
Netflix	Media
YouTube	Shift + Media
☼1	Format
☼2	3D
Red	Red

Original		Replacement		Original		Replacement	
	Green	B	Green				
	Yellow	C	Yellow				
	Blue	D	Blue				
	<<		<<				
	Pause		Pause				
	>>		>>				
	Rec	REC MODE	Rec				
	Play	PLAY MODE	Play				
	Stop		Stop				