Mandis shop

Epson HA23

Original		Replacement		Original	Replacement
	Power		Power		
	Back	RETURN BACK	Back / Return		
	Up		Up		
	Left		Left		
Enter	Enter	OK	OK		
	Right		Right		
	Down		Down		
	<<	TUNE-	<< / Tune-		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	>>	TUNE+	>> / Tune+		
	☼	HOME MENU	Menu / Home		
	Vol +	VOL +	Vol +		
	Source	RDS AV INPUT	AV / Input / RDS		
	Mute	DIMMER MUTE	Mute / Dimmer		
	Vol -	VOL −	Vol -		
	Keystone	LIST SMART	Smart / List		

https://remotecontrols.com/Epson/1675-966-replacement-remote-control-for-Epson-HA23-208270.htm