Mandis shop

REMCON2119

Original		Replacement		Original		Replacement	
ON/OFF	On/Off		Power				
Mode	Mode	FORMAT PICTURE	Picture / Format				
Fan Speed	Fan Speed	LIST SMART	Smart / List				
Up	+/Up	CH PAGE +	CH+ / Page+				
Timer	Timer	TIMER SLEEP	Sleep / Timer				
Down	-/Down	CH PAGE −	CH- / Page-				

https://remotecontrols.dk/en/1068077-96831-replacement-remote-control-for-REMCON2119.html