Mandis shop

REMCON1434

Original	Replacement	Original	Replacement
Power	Power	Vol -	Vol -
TV/FM	TV/R	CH+	Ch +
Scan	Smart	CH-	Ch -
Zoom	Eject	Mute	Mute
1	1	Source	AV
2	2	+	Right
3	3	-	Left
4	4	Function	Ok
5	5	Freq Up	>>
6	6	Freq Down	<<
7	7	Freeze	Pause
8	8	Reset	Exit
9	9	Seek ↑	Up
0	0	Seek ↓	Down
+100	Guide		
Loop	Pre Ch		
Vol +	Vol +		

https://remcontrols.com/Best-By/1507-829-replacement-remote-control-for-Best-By-REMCON1434.html